

# How to select Audio output on the Zebrix player

## Step 1

Power on the NUC player, then press “F1” key.



## Step 2

You can select “audio setting” with “F3” key.



## Step 3

Go on “configuration” menu.



## Step 4

Select the right audio output.

From:

<https://documentation.zebrix.net/> - zebrix documentation



Permanent link:

[https://documentation.zebrix.net/doku.php?id=en:activer\\_le\\_son\\_nuc](https://documentation.zebrix.net/doku.php?id=en:activer_le_son_nuc)

Last update: **2024/02/15 08:48**