

# How to select Audio output on the NUC player

## Etape 1

Power on the NUC player, then press "F1" key.



## Etape 2

You can select "audio setting" with "F3" key.



## Etape 3

Go on "configuration" menu.



## Etape 4

Select the right audio output.

From:  
<https://documentation.zebrix.net/> - **zebrix signage documentation**

Permanent link:  
[https://documentation.zebrix.net/doku.php?id=en:activer\\_le\\_son\\_nuc&rev=1629880175](https://documentation.zebrix.net/doku.php?id=en:activer_le_son_nuc&rev=1629880175)

Last update: **2021/08/25 10:29**

