

Configuring a SAMSUNG monitor with DHCP

Step 1

Take the screen's remote control.

Step 2

Switch on the screen and select the "PC" source. (SOURCE > PC on the remote control)



Step 3

Once the PC source has been selected, press the "MENU" button.



Step 4

In the menu, use the directional arrows to select “Network” and then confirm.




Step 5

Move to “Network status” then “IP Settings” (this button only appears at the end of the connectivity test, or as soon as you have interrupted it using the “STOP” button).



Step 6

- Select "Get automatically".
- Confirm with "OK".



From:
<https://documentation.zebrix.net/> - **zebrix documentation**

Permanent link:
https://documentation.zebrix.net/doku.php?id=en:configuration_dhcp_sssp

Last update: **2024/02/12 10:31**

