Initial Setup - Tizen 7 Screen

Follow the steps below using the Samsung remote control.

1 - Language Selection


Use the arrow keys to scroll and select "French" with the OK button (between the arrows).

Press the right arrow to proceed to the next menu.



2 - Connect to a Network

You can connect the device via a wireless network (Wi-Fi) or a wired connection (RJ45) depending on your setup. Select the option with the OK button.




Wired: The screen will check the network status. If everything is OK, press the right arrow to continue.


2025/12/18 18:07 3/17 Initial Setup – Tizen 7 Screen



Wi-Fi: Select your network and enter the password, then press Finish. (A secure Wi-Fi connection is required.) The screen will verify the connection; if everything is OK, press the right arrow to continue.







• For connection issues, contact Manganelli support at 03.20.41.59.69

3 - Smart Signage Privacy Notice

Press OK, then the right arrow to continue.

2025/12/18 18:07 5/17 Initial Setup - Tizen 7 Screen



4 - Installation Type

Select "Manual Setup" with the OK button.



5 - Display Orientation

Choose portrait or landscape according to your setup and confirm.

Press the right arrow to proceed.



6 - Player Selection

Select "Custom Application" with the OK button.

2025/12/18 18:07 7/17 Initial Setup - Tizen 7 Screen




Enter the Zebrix server URL:

USA: http://screen.zebrix.us

Europe: http://screen.zebrix.net

Click "Finish."



7 - Configure the RM Server

Enter the server address: rm.manganelli.com:7001


Press "Finish" and then the right arrow to continue.



8 - Server Device


No action needed, just press the right arrow.

2025/12/18 18:07 9/17 Initial Setup - Tizen 7 Screen



9 - Power Off Settings


Select "Off" and press the right arrow to continue.



10 - Date and Time Settings

Use the arrows to set the correct date and time. \triangle Incorrect settings may cause display issues.

Press the right arrow to continue.



11 - Pin Code

No action needed, just press the right arrow.




12 - Auto Source Change

Press MENU, navigate to System > Auto Source Change.




Select Auto Source Change > New Input.

Use the arrows to select Default Input > Custom Application.




13 - Set Up Wake-Up Timer

Press HOME, then navigate to Settings > Prog. On/Off using the right arrow.




Select Prog. On.



2025/12/18 18:07 13/17 Initial Setup - Tizen 7 Screen

For Prog. On 1 and Prog. On 2, change from "Do not use" to select the days and set wake-up times according to the business hours.





14 - Power Settings

Press MENU, navigate to System > Power Settings.



Enable the settings as shown in the image.



☐ Configuration is complete!



Launch the app by pressing "Home."


Go to the "Functions" tab and select "Custom APP."





Once the app is launched, the content will be displayed.

If this setup is during an installation, the screen may request activation. Contact support if this occurs.



https://documentation.zebrix.net/ - zebrix documentation

Permanent link: https://documentation.zebrix.net/doku.php?id=en:configuration_initiale_ecrans_tizen7&rev=1760023410

Last update: 2025/10/09 17:23

