

# zebrix on QBIC devices



## tested devices

model	comments
BXP100	Entry-level FULL HD model, suitable for simple projects, limited performance for animations (transition effects, animated widgets, HTML5 animations)
BXP300	Mid-range FULL HD model, good animation performance
BXP320/321	Mid-range 4K model for non-intensive use
BXP350	High-end 4K model - DUAL HDMI - intensive use - high performance level
TD1070 Lite	Ideal for projects with FULL HD content

## zebrix installation procedure on QBIC devices

- Plug a USB keyboard into the player
- Power on the player (or press **ESC** to exit the current application) to access the home menu (DATE & Time, Ethernet, Wifi, Settings)
- On a previously used device, it is always recommended to perform a factory reset: **SETTINGS > Reset Options > Erase all data (factory reset)**
- After reboot, make sure the **date and time** are correct (otherwise, connection to the zebrix server may fail)
- Configure the **network settings** according to your preferences, **internet connection is required** for the next steps
- Go to the **SETTINGS** section
- Go to **Remote APP upgrade URL**, enter <https://screen.zebrix.net/qbic>, check the **Upgrade in background** box, and validate by pressing **SET**
- After a few seconds, the player displays a notification confirming that the application has been downloaded; the application is now set as the default application
- It is recommended to go to the **Player settings** section and enable **Fullscreen mode**, which prevents the navigation bar from appearing at the bottom of the screen (must be disabled if using touch)
- Return to the home screen; the zebrix application will automatically start at the end of the countdown
- At the first launch of zebrix, you must confirm the server to use (Europe: <https://screen.zebrix.net>)
- The zebrix activation page will be displayed, follow the instructions to activate the screen on your zebrix account

## Settings for touch mode usage

In order to prevent users of the touch screen from accessing the Android player settings, it is absolutely necessary to enable the following settings:

- **Settings > Player settings** and enable **Fullscreen mode**, which prevents the navigation bar from appearing at the bottom of the screen, allowing the user to exit the zebrix application.
- **Settings > Security Password** and set a password to restrict access to the player's settings.

From:  
<https://documentation.zebrix.net/> - **zebrix documentation**

Permanent link:  
[https://documentation.zebrix.net/doku.php?id=en:connect\\_qbic\\_to\\_zebrix&rev=1758207871](https://documentation.zebrix.net/doku.php?id=en:connect_qbic_to_zebrix&rev=1758207871)

Last update: **2025/09/18 17:04**

