

Wifi screen connection guide

1 - Go to "Menu" then "Network"



2- Then go to "Open Network Settings"



3 - In "Network Type" select "Wireless" and validate with the "OK" key



4- The screen launches an update of the available wireless networks



5 - Once the search is finished, you will have to select the wifi network of your agency or the wifi network of your smartphone. Then press the "Ok" button to validate it.



6 - A virtual keyboard appears to enter the wifi key (provided by your ISP, or in the connection sharing menu of your smartphone). Enter the key then validate with the "Done" button



7 - The screen will check its connection to the network and once the connection is established you will get the message "Your device is connected to the Internet".



- 8 - Exit the menu with the "Exit" button or by pressing the "Return" button several times



9 - To launch the zebrix application you just have to do "Home" then "Zebrix, URL Launcher", the application will load with to launch



10 - Once completed, the content is distributed



From:

<https://documentation.zebrix.net/> - **zebrix documentation**

Permanent link:

https://documentation.zebrix.net/doku.php?id=en:connexion_ecran_wifi&rev=1672927615

Last update: **2023/01/05 15:06**

