How to set up a video wall with Samsung screens

Step 1

Press the “HOME” button on your remote control.

Step 2

Use the navigation arrows to go to the “Video Wall” menu.

Step 3

Enable the “Video Wall” option by setting it to ON.

Step 4

Configure the following settings:

Video wall size: number of screens arranged horizontally and vertically

Screen position: position of each screen within the video wall

“Full” mode: displays the entire, uncropped picture (may not be suitable due to screen bezels)

“Natural” mode: adjusts for screen bezels to provide a more uniform overall image (the picture is automatically cropped to achieve this result)

Step 5

Assign each screen its position in the menu according to its actual physical position on the video wall, then connect the screens as follows:

Warning: connection ports may vary depending on the screen model. It is recommended to use identical screen models to build a video wall.

Example: Samsung Tizen PM series

The first screen receives the source signal (for example, from a Zebrix player). → Connect the Zebrix player to the first screen using an HDMI cable.

The second screen receives the signal from the first via a DisplayPort cable. → Connect a DisplayPort cable from the DP*OUT port of the first screen to the DP*IN port of the second screen.

Repeat this process for all remaining screens until the entire video wall is connected.

Once all screens are connected, power on the video wall and verify the configuration.

From:
https://documentation.zebrix.net/ - **zebrix signage documentation**

Permanent link:
https://documentation.zebrix.net/doku.php?id=en:how_to_setup_a_video_wall

Last update: **2025/10/13 09:17**